| Monthly Inspection Record for Gantry Crane |   |                     |
|--|---|---------------------|
| Crane Model & Location of Use:             |   |                     |
| Inspection                                 | Requirements  | Result              |
| Structure                                  | Check for deformation, cracks, fatigue                          | 🗆 Normal 🗆 Abnormal |
|  | Check if the main connections are secure and tested             | 🗆 Normal 🗆 Abnormal |
|  | Check bolts, pins, joints for integrity and correct positioning | 🗆 Normal 🗆 Abnormal |
|  | Check if track alignment is level                               | 🗆 Normal 🗆 Abnormal |
| Hoisting<br>Mechanism                      | Check wire rope for kinks, broken wires, good lubrication       | 🗆 Normal 🗆 Abnormal |
|  | Check wire rope fixing and length marks                         | 🗆 Normal 🗆 Abnormal |
|  | Check pulleys, hooks, slings for wear and limits                | 🗆 Normal 🗆 Abnormal |
|  | Check drums and ropes for damage or cracks                      | 🗆 Normal 🗆 Abnormal |
| Transmission<br>System                     | Check gearbox for smooth operation, abnormal sounds             | 🗆 Normal 🗆 Abnormal |
|  | Check lubrication, labels, and oil levels                       | 🗆 Normal 🗆 Abnormal |
|  | Check brakes for sensitivity and complete linkage               | 🗆 Normal 🗆 Abnormal |
|  | Check hoist motor reliability and gear wear                     | 🗆 Normal 🗆 Abnormal |
| Electrical<br>System                       | Check main power for normal function                            | 🗆 Normal 🗆 Abnormal |
|  | Inspect cables and wiring for aging or damage                   | 🗆 Normal 🗆 Abnormal |
|  | Check electrical components, buttons, connectors                | 🗆 Normal 🗆 Abnormal |
|  | Check meters and indicators                                     | 🗆 Normal 🗆 Abnormal |
|  | Check grounding and electrical safety devices                   | 🗆 Normal 🗆 Abnormal |
|  | Check if power supply is stable and balanced                    | 🗆 Normal 🗆 Abnormal |
| Safety &<br>Limit<br>Devices               | Check upper/lower travel limit for reliability                  | 🗆 Normal 🗆 Abnormal |
|  | Check trolley travel limit for reliability                      | 🗆 Normal 🗆 Abnormal |
|  | Check travel limit switches for proper installation             | 🗆 Normal 🗆 Abnormal |
|  | Check warning devices for proper function                       | 🗆 Normal 🗆 Abnormal |
|  | Check for anti-fall safety equipment                            | 🗆 Normal 🗆 Abnormal |
| Inspection Conclusion:                     |   |                     |
| (To be filled in)                          |   |                     |
|  |   |                     |
| Inspector's Signature:                     |   |                     |
| (To be signed)                             |   |                     |

(To be signed)

Date: